

## Universal Transducer Adapters for NDE/NDT Research

Verasonics' Universal Transducer Adapters (UTAs) enable Vantage<sup>™</sup> system users to quickly convert their system to operate transducers with a variety of connectors. Changing from one UTA to another is simple and takes only a few minutes. The user loosens a set of screws by hand, changes the UTA and re-tightens the screws. The Vantage system must be shut down before, and re-booted after, the UTA changeover.

One UTA adapter is included with every Vantage system purchase. Additional adapters are available to meet changing research needs; older Vantage systems can be upgraded to the latest UTA technology.

## **Benefits of Verasonics' UTA technology:**

- Enables use of high-performance, low noise connectors
- Allows for transducers up to 256 elements without a multiplexer
- Provides additional signal paths for probes requiring additional grounding, power supply, digital control signals, etc.
- Retains compatibility with Verasonics transducers, as well as transducers from a variety of supplier partners



The UTA can be changed in a few minutes — no tools required

Adapter Name	Vantage 32 LE	Vantage 64	Vantage 64 LE	Vantage 128	Vantage 256
UTA 128 LEMO			$\checkmark$	$\checkmark$	$\checkmark$
UTA 64 LEMO	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
UTA 160-DH/32 LEMO	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
UTA 160-SH/8 LEMO	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
UTA 160-SI/8 LEMO	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$

 $\checkmark$  Purchasable configuration or option. All Vantage systems can be reconfigured or upgraded to additional options.



## **UTA 128 LEMO**

The UTA 128 LEMO adapter provides direct transmit and/or receive channel connections for up to 128 single element transducers. 2 LEMO to BNC adapters are included. UTA 64 LEMO The UTA 64 LEMO adapter provides direct transmit and/or receive channel connections for up to 64 single element transducers. 2 LEMO to BNC adapters are included. UTA 160-DH/32 LEMO The UTA 160-DH/32 LEMO adapter provides 2 Hypertronics 160-pin connectors in addition to 32 single-channel LEMO connectors.



UTA 160-SH/8 LEMO The UTA 160-SH/8 LEMO adapter provides a single Hypertronics 160-pin connector in addition to 8 single-channel LEMO connectors.



UTA 160-SI/8 LEMO The UTA 160-SI/8 LEMO adapter has one I-PEX phased array connector and 8 single-channel LEMO connectors.

Verasonics Inc. 11335 NE 122nd Way, Suite 100, Kirkland, WA 98034 www.verasonics.com | sales@verasonics.com | 425.998.9836



*Verasonics reserves the right to change specifications without notice.* © *Verasonics, Inc. 2022. All rights reserved.* 4001-2022-81