

Vantage and Vantage NXT UTA Compatibility Matrix



System Configuration	Vantage NXT 32LE	Vantage NXT 64	Vantage NXT 64LE	Vantage NXT 128	Vantage NXT 256	Vantage 32LE	Vantage 64	Vantage 64LE	Vantage 128	Vantage 256
NXT UTA 260-S					128 channels only					128 channels only
NXT UTA 260-D			64 channels /connector	64 channels /connector				64 channels /connector	64 channels /connector	
NXT UTA 260-MUX			64 channels only	64 channels only	64 channels only			64 channels only	64 channels only	64 channels only
NXT UTA 408-GE			128 channels only	128 channels only				128 channels only	128 channels only	
NXT UTA 408-GE MUX			64 channels only	64 channels only	64 channels only					
NXT UTA 160-DH/32 LEMO	32 channels /connector	32 channels /connector	64 channels /connector	64 channels /connector	Full 128 channels /connector	32 channels /connector	32 channels /connector	64 channels /connector	64 channels /connector	Full 128 channels /connector
NXT UTA 160-SH/8 LEMO	64 channels only	64 channels only	128 channels only	128 channels only	128 channels only	64 channels only	64 channels only	128 channels only	128 channels only	128 channels only
NXT UTA 160-SI/8 LEMO	64 channels only	64 channels only	128 channels only	128 channels only	128 channels only	64 channels only	64 channels only	128 channels only	128 channels only	128 channels only
NXT UTA 128 LEMO					128 channels only					128 channels only
NXT UTA 64 LEMO			64 channels only	64 channels only	64 channels only			64 channels only	64 channels only	64 channels only
NXT UTA 256 Direct	64 channels only	64 channels only	128 channels only	128 channels only		64 channels only	64 channels only	128 channels only	128 channels only	
NXT UTA 1024-MUX										
UTA 260-S					128 channels only	64 channels only	64 channels only			
UTA 260-D			64 channels /connector	64 channels /connector				64 channels /connector	64 channels /connector	
UTA 260-MUX			64 channels only	64 channels only	64 channels only					
UTA 360										
UTA 408									128 channels only	All 256 channels
UTA 408-GE			128 channels only	128 channels only				128 channels only	128 channels only	All 256 channels
UTA 160-DH/32 LEMO	32 channels /connector	32 channels /connector	64 channels /connector	64 channels /connector	Full 128 channels /connector	32 channels /connector	32 channels /connector	64 channels /connector	64 channels /connector	Full 128 channels /connector
UTA 160-SH/8 LEMO	64 channels only	64 channels only	128 channels only	128 channels only	128 channels only	64 channels only	64 channels only			
UTA 160-SI/8 LEMO	64 channels only	64 channels only	128 channels only	128 channels only	128 channels only	64 channels only	64 channels only			
UTA 128 LEMO					128 channels only	64 channels only	64 channels only			
UTA 64 LEMO			64 channels only	64 channels only	64 channels only					
UTA 256 Direct	64 channels only	64 channels only	128 channels only	128 channels only		64 channels only	64 channels only	128 channels only	128 channels only	
UTA 1024-MUX										
UTA 156-U										

Indicates that the UTA module is supported and is tested for imaging performance

Indicates that the UTA module is recognized by the system

Indicates that the UTA module is not supported by the system